

Start with an 18" stake. Drive into the ground until further movement is difficult. Level and adjust form. Attach stake to form. Cut top of stake flush with top of form.

Concrete Form

1 of 1

D. Bohmer '09